

ADAPTER



Part No.	Pipe Size P-PT, NPT	Dimensions		
		A	E	F
KFI-A-02	1/8	25.4	5	9/16
KFI-A-04	1/4	35	7	3/4
KFI-A-06	3/8	40	9.5	7/8
KFI-A-08	1/2	40	12	1-1/16
KFI-A-12	3/4	50	15	1-1/4
KFI-A-16	1	58	22	1-5/8

A - Length (mm), E - Through Bore (mm), F - Hex (Inch)